


720W Platinum Rated AC/DC Reference Design

Demo Instructions



Board Overview



July 2012 2




What's Included?

- 720W AC/DC Power Supply
- AC Power Cable
- Load Cable Adapter




 Visually Inspect the System to ensure no damage has been caused during shipping.






 The highlighted section may carry high voltage so be careful when lid is open.






 The output connector is in the highlighted location shown below






 The output adapter has four screw terminals.
Connect the Electronic load taking care of polarities as shown in the picture



July 2012 7



 Before powering on for the first time, ensure that the Electronic Load is ON and configured for 0A current.






- Before connecting the AC Power cable, ensure that the AC source is turned OFF
- Make sure that the AC source has an Earth connection to the Earth pin of the AC input connector

Earth Pin






AC Input Connector



- If desired, connect the input cable to a power quality meter to measure Power factor and THD. Follow the recommended connections for the power meter.
- Connect the AC Power Cable to the AC Input Connector and turn ON the AC source

AC Input Connector ____





Precautions

- Do not operate the system with the Lid open
- Always operate the AC/DC Power Supply within the published specifications
- Contact Microchip for any questions or concerns



Measurements and Tests

- Use the power meter to measure input Power Factor and THD
- To record efficiency measurements, follow the guidelines provided in Platinum AC_DC Efficiency Measurement Guidlines
- For dynamic load response ensure that the slew rate is ≤ 2A/us



Additional Support

- www.microchip.com/smps
- http://support.microchip.com
- Contact your local Microchip FAE

July 2012 13